

Offering & Creating an Image USB Product

Image USB, or "Burn to USB" was introduced in APM v10, and allows users to select images at the kiosk to be copied onto a USB drive from Lab 50 or Print 50.

The USB, DVD and CD are all what we call Image Archives. The user can only pick one of these archive types per order... so she could not order both a DVD and a USB in the same order.

Offering the product on the kiosk

1. in Setup Wizard, go to **Kiosk Settings > Image CD/DVD/USB Settings**
2. Check off **Offer Image USB** and adjust the capacity settings and default fulfillment. The default fulfillment is what will be used when the product is selected from the main menu. The product can also be ordered as an order options add-on, after prints are ordered.

Notes:

- The USB will be created via Lab 50 or Print 50, kiosk creation is not available.
- There can only be one default fulfillment set for all archiving products.

The screenshot shows the 'SetupWizard' window with the 'Image CD/DVD/USB Settings' tab selected. The left sidebar lists various settings categories, with 'Image CD/DVD/USB Settings' highlighted. The main panel contains the following sections:

- Image Archiving Order Options:** Includes checkboxes for 'Offer Image CD', 'Offer Image DVD', and 'Offer Image USB' (which is checked and highlighted in yellow). Capacity settings are shown: CD Capacity (MB) at 650, DVD Capacity (MB) at 4400, and USB Stick Capacity (MB) at 8000 (highlighted in yellow). A 'Default Fulfillment' dropdown is set to 'Fulfillment #1 (Express)'.
- Image CD/DVD Settings:** Includes radio buttons for 'Burn Image CD/DVD remotely via Back Lab Burner or supported minilab.' and 'Burn Image CD/DVD at APM' (which is selected).
- Image CD/DVD/USB Content Settings:** Includes checkboxes for 'Include copy of original photos on Image CD/DVD/USB (in addition to edited photos)' and 'Archive non-photo media files on Image CD/DVD. (Only applicable if burned at APM)'. A 'Types:' text box lists supported file formats: avi, mov, moov, mpg, mpeg, mp4, wmv, aac, ac3, aif, aiff, asf, divx, dv, mp2, mp3, qt, wav, wma.
- Drive Settings:** Includes dropdowns for 'CD-R/DVD-R Drive Letter' (set to 'D') and 'CD-R/DVD-R Drive Index' (set to '0').

3. Next, click on the **Fulfillment** you selected as default in the pulldown in the previous step. Click **Main Options** and under Order Option, check the box for Image CD/DVD/USB.

SetupWizard
File Help

Fulfillment #2 (Pick Up)

Settings:
Main Options
Order Settings
Payment Settings

Kiosk Text Settings:
Fulfillment Title
Fulfillment Description
Order Completion Text

Products:
Add Product(s)
4x6 Prints (Quick Order Product)
5x7 Prints
8x10 Prints
8x12 Prints
11x14 Prints
12x18 Prints
16x20 Prints
16x24 Prints
20x30 Prints
24x36 Prints
Passport Photo
8x6 Photo Book Cover
11x8.5 Photo Book Cover
6x4 Flat Card
7x5 Flat Card
8x6 Flat Card
4x6 Flat Card
5x7 Flat Card
6x8 Flat Card
Scrapbook Page 4x4
Scrapbook Page 5x5
Scrapbook Page 6x6
Scrapbook Page 8x8
Scrapbook Page 10x10
Scrapbook Page 12x12

Kiosk Settings:
Fulfillment #1 (Express)
Fulfillment #2 (Pick Up)
Fulfillment #3 (Mail)
APM Add-On Components
Printer Configuration

Main Options

☒ Enable this fulfillment.

Print Settings:
☐ This fulfillment prints on a local printer connected to this APM. ☐ Monitor Printing
☒ This fulfillment prints at a Lab 50 / Print Station connected via a LAN.
☐ This fulfillment prints remotely, connected via a private FTP server.
☐ This fulfillment prints at a remote Lab 50 / Print Station connected via APM Order Agent.

Order Options:
☒ Image CD/DVD/USB ☐ White Borders ☐ Special Instructions
☒ Index Print ☐ Shrink to Fit ☐ Auto-Enhance All Photos
☐ Card Catalog ☐ DVD Cinema ☐ Auto Red Eye Fix All Photos
☐ Glossy/Matte ☐ Web Uploads

Photo IQ Options:
Red Eye Removal: ☒ Automatic ☐ Manual ☐ Both ☐ Off
Color Correction: ☒ Automatic ☐ Manual ☐ Both ☐ Off ☐ Hide Auto Color Correction
Cropping: ☒ On ☐ Off
Photo Borders: ☒ On ☐ Off
Text on Photo: ☒ On ☐ Off
Copy Photo: ☒ On ☐ Off

4. The Image USB product should already be showing in the list (checking the box in Step 2 triggers this). Now, click on **Image USB** that now shows up in the Products list. Configure settings. Info about the settings:
- Product Name:** shows in the shopping cart, order summary and receipt
 - Short Name:** shows in the kiosk UI on the product selection
 - Base Price:** If you want just one price per drive, no matter the qty, enter only the base price and you are done.
 - Quantity Prices:** If you want to give a discounted price for customers ordering a certain qty, set that up using the qty system.

Example: base is \$14.95, qty 2 is \$10, qty 5 is \$5. This means that if I order 1, it's \$14.95. If I order 2, my total is \$20. If I order 4 my total is \$40. If I order 5 my total is \$25.

SetupWizard
File Help

Fulfillment #2 (Pick Up)

Settings:
Main Options
Order Settings
Payment Settings

Kiosk Text Settings:
Fulfillment Title
Fulfillment Description
Order Completion Text

Products:
Add Product(s)
Passport Photo
7x5 Flat Card
7x5 FR-CA Flat Card
Image USB
FR-CA 11oz Photo Mug
FR-CA Travel Mug
Travel Mug
11oz Photo Mug
8x8 Metal Collage
7x5 Chromalux Flat Metal - 7.25x5.25 ou
7x5 Hardboard Panel - 7.25x5.25 output
7x5 Chromalux Flat Metal (FR) - 7.25x5.25

Kiosk Settings:
Fulfillment #1 (Express)
Fulfillment #2 (Pick Up)
Fulfillment #3 (Mail)
APM Add-On Components

Product USB Drive - (Internal ID: 2049)

Product Name:

Short Name:

Base Price:

Quantity Pricing
☒ Enable Quantity Pricing for this product and fulfillment.

1)	Qty: 2	Price: 10.00
2)	Qty: 5	Price: 5.00
3)	Qty:	Price:
4)	Qty:	Price:
5)	Qty:	Price:
6)	Qty:	Price:

5. Repeat **Steps 3 and 4** for each fulfillment where you want to offer the product.

Kiosk experience

There are two ways the user can buy an Image USB.

Method 1: I know what i want!

I want to choose my images, and have you put them on a USB!

Here, the user selects the archive product group from the main menu, then picks USB Drive (this is where your short name comes in), then chooses the images to be included on the drive.

The prices here are whatever you set in the fulfillment you marked as default for the archive product (from Step 2 above). If you have quantity prices set, the Price box will keep up with the calculation as the user changes the quantity.



Method 2: I was upsold!

I put in my prints/creative order, but what's this I see being offered, an Image USB!?! Yes please!

Here, the user opted for Prints (or could have done a creative product too), and when that is done, was presented with the option to add an Image USB. If you have the Image USB set up for multiple enabled fulfillments, the pricing for whichever fulfillment the user picked will be used. With this option, the user can choose to include all the photos from his or her session, or can elect to use only the ones he or she has ordered.




Production of the Image USB


The Image USB is made through Lab 50 or Print 50. There is no option to create the USB at the kiosk, like you can do with discs.

To create the Image USB:

1. Setup: In Lab 50, set your output folder under Settings > Fulfillment > Media Output.



2. Right-click the order and choose the new "Export Media Products" option instead of a typical Export.



3. This will save the applicable photos to the folder you defined in step 1, where you can then copy them to the USB stick.
4. Open that folder, open the drive where the USB is plugged in and copy over the images.

FAQ

1. Do I need to use Lab 50 to create the USB?
 - a. Yes. (Or Print 50).
2. Are you going to ever have it like the DVDs, where you can "burn" it at the kiosk?
 - a. This is not planned for the short term. Long term remains to be decided.
3. Does it matter what device was used when ordering the USB (phone versus a memory card)?
 - a. No.